# **DHCP:**

To give IP address to devices.

### Router setup:

enable

config t

hostname R1

int fa 0/0

ip address 200.1.1.254 255.255.255.0

no sh

exit

### **Router as DHCP:**

config t

ip dhcp pool A (A is just a name)

network 200.1.1.0 255.255.255.0 (0 to 255 range to share ips)

dedult-router 200.1.1.254 (gateway, jis interface par ya ip hai ussay is subnet mask mai sai IP dena)

dns-server 8.8.8.8

exit

#### **Exclude IPs:**

config t


ip dhcp excluded-address 200.1.1.240 200.1.1.254 ( ya ip range sai nikal kar humnay reserve kiya hain)

### **IP Configurations on PC:**

ip configuration

## dhcp→static

### static←dhcp



DHCP: